
FINLIN

INSTALLATION INSTRUCTIONS | FEBRUARY 2023





- Attach the luminaire to the mounting base with the upper side first and tilt towards the wall as shown.
- 4 Fix the luminaire on the base with the socket screw.







3

4









DISMOUNTING AND RECYCLING INSTRUCTIONS Light source & driver

- Remove the luminaire from the mounting base by loosening the socket screw.
- 2 Loosen the wires and remove the driver.
- Remove the endcap an pull out light source.



The light source is replaceable by an authorized professional.

For advice contact your Wever & Ducré customer service contact point.



The driver can be replaced by the end user.



This luminaire contains a light source with the energy class F.

