
IC F2

Designed by Michael Anastassiades, 2014


F3174030



FLOS

EN





- 01. F3137030A Glass diffuser 2 assembly for black version
- 02. RF28045 Led 220-240V 40-250W 4-100W Rondò dimmer
- 03. RF3130100 Screw kit with Allen key for base assembly

REV. 1 DATE 12/07/2021


EΝ

IC F2 F3174030

F3137030A

GLASS DIFFUSER 2 ASSEMBLY FOR BLACK VERSION





REV. 1 DATE 12/07/2021

EΝ

IC F2 F3174030

F3137030A

GLASS DIFFUSER 2 ASSEMBLY FOR BLACK VERSION




Fig.1

Assemble the glass diffuser (E) by fastening it delicately to the lamp body's ferrule (F).

REV. 2 DATE 21/04/2022


EΝ

IC F2 F3174030

RF28045

LED 220/240V 40-250W 4-100W RONDO' DIMMER





FLOS

EN

IC F2 F3174030

RF28045

LED 220/240V 40-250W 4-100W RONDO' DIMMER



Fig.1



Fig.2

Open the box of the damaged dimmer. For the opening, it is necessary to remove the rubber pad from underneath the dimmer box;

Unfasten the screw that locks the triangle terminal cover.

ΕN

IC F2 F3174030

RF28045

LED 220/240V 40-250W 4-100W RONDO' DIMMER



Fig.3



Fig.4

Turn the dimmer box and remove the terminal cover;

Unfasten the three screws of the cable clamps;

EN

IC F2 F3174030

RF28045

LED 220/240V 40-250W 4-100W RONDO' DIMMER



Fig.5



Fig.6

Remove the cable clamp and disconnect the cables from the green terminal box.

Assemble now the new dimmer: Connect the cables respecting the polarities, lock the wires by positioning the cable clamp and then fasten the three screws, cover the green terminal box with the triangle cover, turn the dimmer box, fasten the screw and stick-on the rubber pads.

REV. 1 DATE 12/07/2021


EN

IC F2 F3174030

RF3130100

SCREW KIT WITH ALLEN KEY FOR BASE ASSEMBLY






EN

IC F2 F3174030

RF3130100

SCREW KIT WITH ALLEN KEY FOR BASE ASSEMBLY





Assemble the base (C) onto the lamp body (B) by fastening the 3 screws (D) with the Allen key supplied with the kit.