


LAST ORDER FLUTED

Designed by Michael Anastassiades, 2020

F3694015






LAST ORDER FLUTED

ΕN

F3694015



01. F3692015A - Satin copper top-cover

02. RF29776 – Led body assembly

03. RF29125 – Crystal Fluted base

04. RF1035109 – Power charger with electrical cable & plugs



LAST ORDER FLUTED F3694015

ΕN

F3692015A

SATIN COPPER TOP COVER







Last Order Fluted p.03

LAST ORDER FLUTED F3694015

F3692015A

SATIN COPPER TOP COVER




Fig.1

Remove the top-cover (A) from the led body (B).

Assemble now the new spare part.



LAST ORDER FLUTED F3694015

RF29776

LED BODY ASSEMBLY







Last Order Fluted p.05

LAST ORDER FLUTED F3694015

ΕN

RF29776

LED BODY ASSEMBLY




Fig.1

Remove the top-cover (A) from the led body (B).

Assemble now the new spare part.



LAST ORDER FLUTED F3694015

RF29125

CRYSTAL FLUTED BASE



LAST ORDER FLUTED F3694015

RF29125

CRYSTAL FLUTED BASE




Fig.1

Remove the crystal base (B) from the led body (A).

Assemble now the new spare part.




LAST ORDER FLUTED F3694015

RF1035109

POWER CHARGER WITH ELECTRICAL CABLE & PLUGS





LAST ORDER FLUTED F3694015

RF1035109

POWER CHARGER WITH ELECTRICAL CABLE & PLUGS




Fig.1

RECHARGING THE BATTERY. Insert the plug (G) in the power adaptor (H) in the preferred working position (the plug can be inserted in any side of the power adaptor block) until you hear the snap-in click (use the correct type of plug for the country the lamp is installed in); to remove the plug press the power adaptor's push button (I). Insert the USB plug (L) of the cable provided in its housing (M) on the power adaptor then insert the micro-USB plug (O) into the lamp's connector (P).