


Designed by Michael Anastassiades, 2020


F3694059





ΕN

F3694059



01. F3692059A - Polished brass top-cover

02. RF29776 – Led body assembly

03. RF29125 – Crystal Fluted base

04. RF1035109 – Power charger with electrical cable & plugs



ΕN

F3692059A

POLISHED BRASS TOP COVER





p.03



Last Order Fluted p.03

LAST ORDER FLUTED F3694059

F3692059A

POLISHED BRASS TOP COVER




Fig.1

Remove the top-cover (A) from the led body (B).

Assemble now the new spare part.

ΕN

RF29776

LED BODY ASSEMBLY





p.05



Last Order Fluted p.05

LAST ORDER FLUTED F3694059

RF29776

LED BODY ASSEMBLY




Fig.1

Remove the top-cover (A) from the led body (B).

Assemble now the new spare part.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

© 2021 Flos - All rights reserved - www.flos.com Flos reserves the right to introduce any changes to its own models, without prior notice.



ΕN

RF29125

CRYSTAL FLUTED BASE



LAST ORDER FLUTED F3694059

RF29125

CRYSTAL FLUTED BASE




Fig.1

Remove the crystal base (B) from the led body (A).

Assemble now the new spare part.




ΕN

RF1035109

POWER CHARGER WITH ELECTRICAL CABLE & PLUGS





LAST ORDER FLUTED F3694059

RF1035109

POWER CHARGER WITH ELECTRICAL CABLE & PLUGS




Fig.1

RECHARGING THE BATTERY. Insert the plug (G) in the power adaptor (H) in the preferred working position (the plug can be inserted in any side of the power adaptor block) until you hear the snap-in click (use the correct type of plug for the country the lamp is installed in); to remove the plug press the power adaptor's push button (I). Insert the USB plug (L) of the cable provided in its housing (M) on the power adaptor then insert the micro-USB plug (O) into the lamp's connector (P).