


## KTRIBE T2

Designed by Philippe Starck, 2007


F6303007



## KTRIBE T2

F6303007

EN



01. F6278007 – Ivory soft diffuser assembly

02. RF32262 – Led dimmer 1004P LFP100-240V 4-150WHL 4-25W

**KTRIBE T2** F6303007

**EN**

## F6278007

IVORY SOFT DIFFUSER ASSEMBLY



Bibliothèque  
Nationale  
p.03



Ktribe  
T2  
p.03



Ktribe  
F2  
p.03

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

KTRIBE T2 F6303007

EN

**F6278007**

IVORY SOFT DIFFUSER ASSEMBLY




Fig.1

Install the external diffuser (A) onto the internal diffuser (B) being careful to make the three pins (C) in the internal diffuser correspond with the relative housings (D) in the external diffuser. Once carried out this operation it is necessary to lock the external diffuser by turning it slightly clockwise.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - [www.flos.com](http://www.flos.com)  
Flos reserves the right to introduce any changes to its own models, without prior notice.

KTRIBE T2 F6303007

EN

## RF32262

LED DIMMER 1004P LFP100-240V 4-150WHL 4-25W



Bedside  
Gun  
p.12



Chiara T  
p.03



Glo-ball  
Basic 0  
p.11



Glo-ball  
Basic 1  
p.14



Glo-ball  
Basic 2  
p.05



Glo-ball  
T1  
p.11



Ic T1  
High  
p.08



Ic T1  
Low  
p.08



Ic T2  
p.08



Ktribe T1  
p.05



Ktribe T2  
p.05



Ray T  
p.17



Romeo  
Moon  
T1  
p.32



Romeo  
Soft T1  
p.32



Spun  
Light  
T1  
p.12



Spun  
Light  
T2  
p.12




Table  
Gun  
p.12

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

KTRIBE T2 F6303007

EN

## RF32262

LED DIMMER 1004P LFP100-240V 4-150WHL 4-25W



Fig.1




Fig.2

Open the dimmer box of the damaged dimmer.  
For the opening, it is necessary to remove the n°2 screws using a star screw driver.

Lift-up the dimmer casing from the dimmer base;

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - [www.flos.com](http://www.flos.com)  
Flos reserves the right to introduce any changes to its own models, without prior notice.

KTRIBE T2 F6303007

EN

## RF32262

LED DIMMER 1004P LFP100-240V 4-150WHL 4-25W





Fig.3



Remove the cable clamps by unfastening the 4 screws (A) and disconnect the wires from the terminal blocks through a tiny flat headed screw driver;




Fig.4

Replace the dimmer and connect the wires. When connecting the wires it is necessary to respect the polarities (L = Brown and N = Blue) to the terminal box. Lock the electrical cables by fastening the screws (A) of the cable clamps and make sure to block the isolation of the electrical cable.

Close the dimmer box. It is necessary to place the casing on top and press down until it locks in. it is necessary to insert the n°2 screws using a star screw driver

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.